

COMBICONTROL



C6

Instruction Manual

C6 HMI / C6 HMI LC

Document	Part	Version
20125246	GBR	00



Content

1	Introductory Information	5
1.1	General notes	6
1.2	Trademarks.....	6
1.3	Instructions on disposal	6
1.4	Description of safety symbols.....	7
1.5	Qualified Personnel	8
1.6	Basic knowledge required	8
1.7	Proper use of the product	8
1.8	Purpose of the user's guide	8
1.9	The manual is a part of the system.....	8
1.10	Figures.....	8
1.11	Scope of the operating instructions	9
1.12	Safety instructions	9
1.12.1	Installation according to the instructions	9
1.12.2	Working on the control cabinet.....	9
1.13	Notes about usage	9
1.14	Applicable standard	9
2	Description	10
2.1	Product description.....	11
2.2	Key features.....	11
2.3	Package	11
2.4	Configuration.....	12
2.4.1	C6 HMI/C6 HMI LC (full aluminium front panel)	12
2.5	Front view	13
2.5.1	Full aluminium front panel	13
2.5.2	Widescreen	14
2.6	Rear view.....	15
2.7	Side view	17
2.8	Connection overview C6 HMI 4.3"	19
2.8.1	Labels.....	19
2.9	Connection overview C6 HMI / C6 HMI LC 5.7" and higher	20
2.9.1	Connection Label.....	20
2.9.2	Nameplate	21
2.10	Touchscreen	21
2.11	Putting in operation C6 HMI / C6 HMI LC.....	22
2.11.1	Configuration and project creation	22
2.11.2	Process management.....	22
2.12	Software options	23
3	Installation and connection	25
3.1	Preparation for installation	26
3.1.1	Select the mounting location	26
3.1.2	Portrait Mounting	26
3.2	Checking the package contents	26
3.3	Checking the operating conditions	26
3.4	Mounting position	27
3.4.1	Damage due to overheating	27
3.5	Checking installation distances.....	28
3.6	Preparing the mounting cut-out	28
3.6.1	Degrees of protection.....	29
3.6.2	Dimensions of the cut-outs.....	29
3.7	Mounting the device	30
3.7.1	Position of the mounting clamps	30
3.7.2	Tools to tighten the mounting clamps.....	31
3.7.3	Procedure	32
3.8	Connecting the unit.....	35
3.8.1	Information for the connection	35
3.8.2	Power supply connection	35
3.8.3	Switching on and testing the device.....	36
3.9	Connecting the configuration PC	37

3.9.1	Procedure	40
4	Commissioning the device.....	43
4.1	Backup design.....	44
4.2	Internal memory.....	44
4.3	Slot for memory card (from 5.7")	45
4.4	Installation/removal of a memory card	45
5	Commissioning a project	48
5.1	COMBIVIS studio HMI project	49
5.1.1	Overview	49
5.1.2	Transfer	49
5.1.3	Configuration the serial port.....	49
5.1.4	Connecting the serial port	51
5.1.5	Project administration.....	51
5.1.6	Stopping the running project	52
5.1.7	Starting the project	53
5.1.8	Debugging the project	54
5.1.9	Transfer the project from C6 HMI / C6 HMI LC to the configuration PC.....	56
5.1.10	Backup and restore.....	57
5.1.11	Update the operating system.....	57
5.2	COMBIVIS studio 6 project	58
5.2.1	C6 HMI LC – Implementation “CONTROL Runtime”	58
5.2.2	Preparing the COMBIVIS studio 6 programming environment	59
5.2.3	Transferring the COMBIVIS studio 6 application to the target system.....	61
5.2.4	I/O Fieldbus	61
5.2.5	Support for retentive data.....	62
5.2.6	Use in combination with COMBIVIS HMI Runtime.....	64
5.2.7	Use in combination with COMBIVIS connect	65
5.2.8	Limitations and Recommendations.....	66
6	Maintenance.....	67
6.1	Calibration of the Touchscreen.....	68
6.2	Maintaining & cleaning	69
6.2.1	Procedure	70
6.2.2	Backup battery replacement (CR2032 3V).....	70
6.3	Technical support & repairs.....	73
6.4	Recycling and disposal	73
7	Technical specifications.....	74
7.1	Technical specifications.....	75
7.1.1	4.3" Display characteristics.....	79
7.1.2	5.7" Display characteristics.....	79
7.1.3	7.0"W Display	79
7.1.4	8.4" Display characteristics.....	79
7.1.5	10.1"W Display characteristics.....	80
7.1.6	10.4" Display characteristics	80
7.1.7	12.1" (SVGA) display characteristics.....	80
7.1.8	12.1"W display characteristics.....	81
7.1.9	15.0" Display characteristics	81
7.1.10	15.6"W Display characteristics	81
7.2	Certificates and approvals.....	82
7.3	Ports PINOUT.....	83
7.3.1	COM1 – DB15M Serial	83
7.3.2	LAN1 – LAN2	83
7.3.3	USB1 / USB2.....	83
7.4	Technical support & repairs.....	84

SECTION **1**

**Introductory
Information**

1.1 General notes

- a) The information in this manual is subject to change and is in no way binding upon KEB.
- b) KEB is not responsible for technical errors or other omissions in the manual, and shall not accept any responsibility deriving from its use.

1.2 Trademarks

- a) All brands and product names mentioned in this manual are trademarks of their respective owners.

1.3 Instructions on disposal



IT

- Il simbolo  sul prodotto o sulla confezione indica che il prodotto non deve essere considerato come un normale rifiuto domestico, ma deve essere portato nel punto di raccolta appropriato per il riciclaggio di apparecchiature elettriche ed elettroniche. Provvedendo a smaltire questo prodotto in modo appropriato, si contribuisce a evitare potenziali conseguenze negative per l'ambiente e la salute, che potrebbero derivare da uno smaltimento inadeguato del prodotto. Per informazioni più dettagliate sul riciclaggio di questo prodotto, contattare l'ufficio comunale, il servizio locale di smaltimento rifiuti o il fornitore da cui è stato acquistato il prodotto.



EN

- The symbol  on the product or in its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the supplier where you purchased the product.



FR

- Le symbole  sur le produit ou son emballage indique que ce produit ne peut être traité comme déchet ménager. Il doit être remis au point de collecte dédié à cet effet (collect et recyclage du matériel électrique et électronique). En procédant à la mise à la casse réglementaire de l'appareil, nous préservons l'environnement et notre sécurité, s'assurant ainsi que les déchets seront traités dans des conditions appropriées. Pour obtenir plus de détails sur le recyclage de ce produit, veuillez prendre contact avec les services de votre commune ou le distributeur où vous avez effectué l'achat.

- | | |
|----|---|
| DE |  <ul style="list-style-type: none"> Das Symbol auf dem Produkt oder seiner Verpackung weist darauf hin, dass dieses Produkt nicht als normaler Haushaltsabfall zu behandeln ist, sondern an einem Sammelpunkt für das Recycling von elektrischen und elektronischen Geräten abgegeben werden muss. Durch ihren Beitrag zum korrekten Entsorgen dieses Produkts schützen Sie die Umwelt und die Gesundheit Ihrer Mitmenschen. Umwelt und Gesundheit werden durch falsches Entsorgen gefährdet. Weitere Informationen über das Recycling dieses Produkts erhalten Sie von Ihrem Rathaus, Ihrer Müllabfuhr oder den Distributoren, in dem Sie das Produkt gekauft haben. |
| ES |  <ul style="list-style-type: none"> El simbolo en el producto o en su embalaje indica que este producto no se puede tratar como desperdicios normales del hogar. Este producto se debe entregar al punto de recolección de equipos eléctricos y electrónicos para reciclaje. Al asegurarse de que este producto se deseche correctamente, usted ayudará a evitar posibles consecuencias negativas para el ambiente y la salud pública, lo qual podría ocurrir si este producto no se manipula de forma adecuada. Para obtener informaciones mas detalladas sobre el reciclaje de este producto, póngase en contacto con la administración de su ciudad, con su servicio de desechos del hogar o con el surtidor donde compró el producto. |
| PT |  <ul style="list-style-type: none"> simbolo no produto ou na embalagem indica que este producto não pode ser tratado como lixo doméstico. Em vez disso, deve ser entregueado ao centro de recolha selectiva para a reciclagem de equipamento eléctrico e electrónico. Ao garantir uma eliminação adequada deste produto, irá ajudar a evitar eventuais consequências negativas para o meio ambiente e para a saúde pública, que, de outra forma, poderiam ser provocadas por um tratamento incorrecto do produto. Para obter informações mais detalhadas sobre a reciclagem deste produto, contacte os serviços municipalizados locais, o centro de recolha selectiva da sua área de residência ou no distribuidor onde adquirir o produto. |

1.4 Description of safety symbols

 Danger	This symbol indicates a danger to life or health of personnel.
 Attention	This symbol indicates a danger to the hardware and / or the environment.
 Note	This symbol indicates an additional information meant to provide a better understanding.

1.5 Qualified Personnel

- a) C6 HMI / C6 HMI LC may be operated only by personnel qualified for the specific task in accordance with the relevant documentation for the specific task, in particular its warning notices and safety instructions.
- b) Qualified personnel are those who, based on their training and experience, are able to identify risks and avoid potential hazards when working with these systems.

1.6 Basic knowledge required

- a) To understand operating instructions a general knowledge of automation technology is needed.
- b) Knowledge of personal computers and the Microsoft operating system is required to understand this user's guide.

1.7 Proper use of the product

- a) KEB products may only be used for the applications described in the catalogue and in the technical documentation.
- b) If products and components from other manufacturers are used, these must be approved by KEB.
- c) Proper transport, assembly, installation, storage, commissioning, operation and maintenance are required to ensure that the product operates safely.
- d) The indicated environmental conditions must be observed.
- e) The information in this user's manual must be observed.

1.8 Purpose of the user's guide

- a) This user's manual contains information based on the requirements defined by DIN EN 62079 for mechanical engineering documentation.
- b) These operating instructions are intended for:
 - 1. Users
 - 2. Commissioning engineers
 - 3. Maintenance personnel
- c) Pay attention at the information in the chapter "Safety instructions".
- d) More information such as operating instructions, examples and reference information, are available in the online help of COMBIVIS studio HMI and COMBIVIS connect.

1.9 The manual is a part of the system

- a) This user's guide belongs to C6 HMI / C6 HMI LC and is also required for commissioning.
- b) Keep all supplied documentation for the entire service life of C6 HMI / C6 HMI LC.

1.10 Figures

- a) This manual contains illustrations of the described devices.
- b) Some details of the illustrations may differ from the device provided.

1.11 Scope of the operating instructions

- c) The operating instructions apply to the C6 HMI / C6 HMI LC family devices in conjunction with the COMBIVIS studio HMI software. The devices are the following:

C6 HMI	5.7"	Full aluminum front panel
	7.0"W	
	8.4"	
	10.1"W	
	10.4"	
	12.1"	
	12.1"W	
	15.0"	
	15.6"W	
	5.7"	
C6 HMI LC	7.0"W	Full aluminum front panel
	8.4"	
	10.1"W	
	10.4"	
	12.1"	
	12.1"W	
	15.0"	
	15.6"W	
	5.7"	
	7.0"W	

1.12 Safety instructions

1.12.1 Installation according to the instructions

- Commissioning the device is prohibited until it has been absolutely ensured that the system in which the device is to be installed complies with all the applicable EU and international regulation.

1.12.2 Working on the control cabinet

- Open equipment**

The device is open equipment. This means that the C6 HMI / C6 HMI LC may only be integrated in housings or cabinets, where it can be operated from the front panel. The cabinet in which C6 HMI / C6 HMI LC is installed may only be accessed with a key or tool and only by trained and authorized personnel.

- Dangerous voltage**

Opening the cabinet may expose high voltage parts. Before opening the cabinet always disconnect the power.

1.13 Notes about usage

- C6 HMI / C6 HMI LC is approved for indoor use only.
- C6 HMI / C6 HMI LC may be damaged if operated outdoors.

1.14 Applicable standard

Please refer to section 8 for details about the relevant standards.

SECTION 2

Description

2.1 Product description

The C6 HMI family is the HMI solution with RISC architecture that allows running COMBIVIS studio HMI and COMBIVIS connect software platforms.

The C6 HMI LC family is the HMI & Control solution that integrates the COMBIVIS studio HMI visualization software and the CONTROL Basic Runtime integrating in one single product both the visualization and the process control part.

Based on ARM Cortex A8 processor and Microsoft Windows Embedded Compact 7 (C7P) operating system, C6 HMI/C6 HMI LC are available in BASIC or ADVANCED version according to COMBIVIS studio HMI runtime installed. The CONTROL Basic Runtime license is of one unique type and enables all the features at ones except for the CONTROL PRO Runtime which is not supported.

2.2 Key features

KEY FEATURES	C6 HMI	C6 HMI LC
O.S. Microsoft Windows Embedded Compact 7 (C7P) installed on flash memory.	X	X
KEB COMBIVIS studio HMI Runtime	X	X
KEB COMBIVIS connect Runtime	X	X
CONTROL Runtime V3.x	-	X
CONTROL PRO Runtime NOT supported		
CPU ARM CORTEX A8 architecture	X	X
Multiple mass memories support:		
<ul style="list-style-type: none"> • NAND: write security memory used to store O.S. and HMI executables • eMMC: fast access memory used for some applications (e.g. CONTROL Runtime) and user data • SD (socket): removable memory 	X	X
Frontal IP 66	X	X
Micro UPS	Option	X

2.3 Package

C6 HMI / C6 HMI LC package consists of:

Table 1
Package

C6 HMI / C6 HMI LC system	
Quick Installation guide	
n.10 Clamps with grub screw (depending on the LCD size)	
n.1 hex key 1.5mm	
n.1 Power supply plug	

2.4 Configuration

The following figures show the various configurations.

2.4.1 C6 HMI/C6 HMI LC (full aluminium front panel)

Figure 1
C6 HMI / C6 HMI LC 5.7"



C6 HMI	4.3"	Full aluminium front panel
	5.7"	
	7.0"W	
	8.4"	
	10.1"W	
	10.4"	
	12.1"	
	12.1"W	
	15.0"	
	15.6"W	

C6 HMI LC	5.7"	Full aluminium front panel
	7.0"W	
	8.4"	
	10.1"W	
	10.4"	
	12.1"	
	12.1"W	
	15.0"	
	15.6"W	

2.5 Front view

2.5.1 Full aluminium front panel




Figure 2
Full aluminium front panel detail

- 1 Full aluminium front panel
- 2 Touchscreen-Display


2.5.2 Widescreen

In the C6 HMI / C6 HMI LC family the systems with 5.7", 8.4", 10.4", 12.1", 15.0" display have a 4:3 aspect ratio, whereas the systems with 4.3", 7.0"W, 10.1"W, 12.1"W and 15.6"W display have a aspect ratio of 15:9 or 16:9.

The 7.0" display provides 25% more surface than the smaller 5.7" size.

2.5.2.1 Widescreen full aluminium front panel

*Figure 3
Full aluminium front panel detail*



- 1 Frame
- 2 Touchscreen-Display

2.6 Rear view

Figure 4
C6 HMI 4.3" rear view






Figure 5
C6 HMI / C6 HMI LC 5.7" rear view




Note: rear panels may be different depending on display size.

Figure 6
C6 HMI / C6 HMI LC 7.0" rear view



Note: the user manual refers to HMI 5.7" version. Other versions will be discussed only when necessary.

Figure 7
C6 HMI / C6 HMI LC 8.4" rear view




2.7 Side view

Figure 8
C6 HMI 4.3" side view




① Aeration holes

Figure 9
C6 HMI 4.3" side view




① Aeration holes
② Recess for fixing clamps

Figure 10
C6 HMI / C6 HMI LC 5.7" side view



- (1) Aeration holes
- (2) Recess for fixing clamps


Figure 11
C6 HMI / C6 HMI LC 5.7" side view



- (1) Aeration holes
- (2) Recess for fixing clamps

2.8 Connection overview C6 HMI 4.3”


Figure 12
C6 HMI 4.3” connectors



2.8.1 Labels


On the rear panel are present the following the connectors label.

Figure 13
C6 HMI / C6 HMI LC connectors label detail



2.9 Connection overview C6 HMI / C6 HMI LC 5.7” and higher


Figure 14
C6 HMI / C6 HMI LC 5.7” connectors



2.9.1 Connection Label

On the rear panel are present the following the connectors label.

Figure 15
C6 HMI / C6 HMI LC connectors label detail



2.9.2 Nameplate

Figure 16
C6 HMI / C6 HMI LC label detail



- (1) Model
- (2) UL marking
- (3) CE marking
- (4) Material number
- (5) Serial number

2.10 Touchscreen

Table 2
Touchscreen

	Size	Touchscreen	Panel technology	
Standard	4.3"	4 - wire	The touchscreen is installed from the back of the front panel. There is a step between the front panel and the touchscreen. The user touches directly the touchscreen.	
	5.7"			
	7.0"W			
	8.4"	5 - wire		
	10.1"W			
	10.4"			
	12.1"			
	12.1"W			
	15.0"			
	15.6"W			

2.11 Putting in operation C6 HMI / C6 HMI LC

To put in operation C6 HMI / C6 HMI LC the followings two phases must be done:

- Configuration and creation of the project of C6 HMI / C6 HMI LC.
- Process management.


2.11.1 Configuration and project creation

During the configuration phase, you create the user interfaces for operation and monitoring of the technical process by using a PC on which is installed COMBIVIS studio HMI development environment. Configuration also includes:

- Creating the project.
- Saving the project.
- Testing the project.
- Simulating the project.

After compiling the configuration, you load the project into the C6 HMI / C6 HMI LC device.


*Figure 17
Configuration and project creation*



2.11.2 Process management

Process management is a two-way communication between HMI device and PLC.

*Figure 18
Process management*



2.12 Software options

*Table 3
Software options*

Function	COMBIVIS studio HMI BASIC for Win CE	COMBIVIS studio HMI ADVANCED for Win CE
RealTime DB	Max. 512 bytes	Max. 4096 bytes
Scaling	Yes	Yes
ODBC Realtime	Yes	Yes
Trace DB	Yes	Yes
Data Structure	Yes	Yes
OPC Client DA	Yes	Yes
Network	Yes	Yes

*Table 4
Graphic interface*

Graphic Interface		
Vectorial Graphic Editor	Yes	Yes
Support for BMP, GIF, JPG, WMF, EMF	Yes	Yes
Dynamic Animation	Yes	Yes
Symbols Library	Yes	Yes
Import/Export Symbols	Yes	Yes
Public Symbols	Yes	Yes
Power Templates (VBA Symbols)	Yes	Yes
Grid	Yes	Yes
Synapsis	Yes	Yes
Scheduler	Yes	Yes
Editing Menu	Yes	Yes
Style Source Management in Symbols	Yes	Yes
IP Camera Viewer	Yes	Yes
Alias management in Objects	Yes	Yes

*Table 5
Alarm log*

Alarm Logs	Max. 512 Alarms	Max. 2048 Alarms
Alarms Management	Yes	Yes
Historical Management (XML)	Yes	Yes
Historical Management (ODBC)	Yes	Yes
Alarms Notification (SMS, Email, Voice)	No	Yes
Alarms Area	Yes	Yes
Comments on alarm ACK	Yes	Yes

*Table 6
Recipes – Data loggers*

Recipes – Data Loggers		
Recipes / Data Logger (XML)	Yes	Yes
Recipes / Data Loggers (ODBC)	Max 2	Yes
Textual Report	Yes	Yes

*Table 7
Trends*

Trends		
Trend RealTime	Yes	Yes
Historical Trends on file.CSV	Yes	Yes
Historical Trends (linked to DataLogger XML)	Yes	Yes
Historical Trends Database (ODBC)	Yes	Yes
Data Analysis	Yes	Yes

*Table 8
Users & Passwords*

Users & Passwords		
Use 1024 levels	Yes	Yes
User Groups	Yes	Yes
CFR21	Yes	Yes
Runtime Users	Yes	Yes

<i>Table 9 Dynamic multilanguage</i>	Dynamic Multilanguage	Yes	Yes
	Unicode support	Yes	Yes
Drivers			
	Max. number of Driver	2	4
	PLC Tag Importer	Yes	Yes
<i>Table 11 Event Object</i>	Event Object	Yes	Yes
<i>Table 12 Scaling Object</i>	Scaling Object	Yes	Yes
<i>Table 13 Scheduler Object</i>	Scheduler Object	Yes	Yes
<i>Table 14 Logics</i>	Logics		
	IL Logic (Step5-Step7)	Yes	Yes
	VBA Logic (WinWrap Basic)	Yes	Yes
	Sinapsis Logic	Yes	Yes
<i>Table 15 Networking</i>	Network	Yes	Yes
<i>Table 16 Child Projects</i>	Child Projects	Yes	Yes
<i>Table 17 Software options</i>	Screen Navigation	Yes	Yes
<i>Table 18 Visual studio source safe 2005 integration</i>	Visual Studio SourceSafe 2005 Integration	Yes	Yes
<i>Table 19 Web Server</i>	Web Server	No	Yes
<i>Table 20 Touch Screen Support</i>	Touch Screen Support	Yes	Yes
<i>Table 21 Cross Reference</i>	Cross Reference	Yes	Yes
<i>Table 22 Debugger</i>	Debugger	Yes	Yes

SECTION 3

Installation and connection

3.1 Preparation for installation

3.1.1 Select the mounting location

Points to observe when selecting the mounting location:

- a) Position C6 HMI / C6 HMI LC to avoid exposure to direct sunlight.
- b) Position C6 HMI / C6 HMI LC such that it is ergonomically accessible for the operator.
- c) Choose a suitable mounting height.
- d) Ensure that the ventilation holes are not covered.

3.1.2 Portrait Mounting

- C6 HMI / C6 HMI LC can be mounted in portrait mode; the display can be rotated according to the mounting position using the dedicated utility from the panel control panel.
- From the Start menu, select "Settings" and then "Control Panel"; the display rotation utility is available from "Freescale Display Driver".
- Double click on the icon to get the window from where you can select the desired orientation.
- The selection is immediately applied and does not require to be saved in the registry.



Note:

See chapter **2.3 Packaging**.

3.2 Checking the package contents

- Check the package content for visible signs of transport damage and for completeness.
- In the case of damaged parts, contact your KEB representative. Do not install parts damaged during shipment.

3.3 Checking the operating conditions

- Read carefully the standards, approvals, EMC parameters and technical specifications for operation of the HMI device. This information is available in the following sections:
 - Certificates and approvals (see section 7).
 - Electromagnetic compatibility (see section 7).
- Check the mechanical and climatic ambient conditions for operation of the HMI device: Ambient conditions (see section 7).
- Follow the instructions for local use of the HMI device: Notes about usage.
- Adhere to the permissible rated voltage and the associated tolerance range:
 - 24V
 - Range: 18÷36 V_{DC}

3.4 Mounting position

The HMI device is suitable for installation in:

- Mounting cabinets
- Control cabinets
- Switchboards
- Consoles

3.4.1 Damage due to overheating

- The operative temperature must be between 0° and 50°C.
- All HMI systems are designed for vertical mounting position.
- An inclined installation reduces the thermal convection by the HMI device and the maximum permissible ambient temperature for operation. Please contact KEB for details.
- The HMI device may otherwise be damaged and its certifications and warranty will be void.



Note:

For installation in control cabinets and in particular, in closed containers, make sure the recommended ambient temperature is maintained.

For further details please refer to section 7 Technical specifications.

*Figure 19
Mounting position*




3.5 Checking installation distances

To ensure adequate ventilation it is necessary leaving the following open spaces around the system:

- **X** direction: (min.) 15 mm for each side.
- **Y** direction: (min.) 50 mm for each side.
- **Z** direction: (min.) 10 mm.

Figure 20
Installation distances



3.6 Preparing the mounting cut-out

In order to ensure a proper mounting of the system, the material of the mounting cut-out must be sufficiently stable.


To obtain the degree of protection described below, the material of the mounting panel must not deform due to the use of clamps on the operator panel.

3.6.1 Degrees of protection

The degrees of protection of the system are guaranteed only if the following conditions are satisfied:

- Material thickness at the mounting cut-out for IP66 protection: 2 mm to 4 mm.
- Deviations of the plane of the mounting cut-out limits: ≤ 0.5 mm.
This condition must also be met with installed C6 HMI / C6 HMI LC.
- Allowed surface roughness in the area of the seal: ≤ 120 microns (Rz 120).

3.6.2 Dimensions of the cut-outs












LCD TFT	A	B	C	D	E	F	G	H	I	K	L	M	N	weight (kg)
4.3"	140	95	5	30	-	5	-	84	-	-	128	131	86	0.7
5.7"	175	145	5	40	-	7	-	131	-	-	161	164	134	0.9
7.0"W	215	155	5	40	-	7	-	141	-	-	201	204	144	1.2
8.4"	255	190	5	19.5	29	7.5	15	130	30	42	156	243	179	1.4
10.1"W	293	201,5	5	19.5	29	6.5	15	130	43.5	62	156	285	193.5	1.6
10.4"	295	230	5	19.5	29	7.5	15	130	70	62	156	283	219	1.8
12.1"	325	260	5	19.5	29	7.5	15	130	100	77	156	313	249	2.1
12.1"W	321	222.5	5	19.5	29	6.3	15	130	65	76	156	313	215	2.0
15.0"	390	305	6	19.5	29	7.5	15	130	145	109.5	156	378	294	3.3
15.6"W	420	265	6	19.5	29	7.5	15	130	105	124.5	156	410	255	3.3

3.7 Mounting the device

3.7.1 Position of the mounting clamps

- To obtain the declared degree of frontal protection for the system, it is necessary to respect the positions of the clamps shown below.
- The table below shows the number and the position of the clamps for each C6 HMI / C6 HMI LC size.

System	Clamp	Quantity	Clamp position
C6 HMI / 4.3"		5	
C6 HMI / C6 HMI LC / 5.7"		7	
C6 HMI / C6 HMI LC / 7.0"W		7	
C6 HMI / C6 HMI LC / 8.4"		8	
C6 HMI / C6 HMI LC / 10.1"W		10	

C6 HMI / C6 HMI LC / 10.4"		10	
C6 HMI / C6 HMI LC / 12.1"		10	
C6 HMI / C6 HMI LC / 12.1"W		10	
C6 HMI / C6 HMI LC / 15.0"		10	
C6 HMI / C6 HMI LC / 15.6"W		10	

3.7.2 Tools to tighten the mounting clamps

- 1.5 mm hexagonal key.

3.7.3 Procedure

1. Insert C6 HMI / C6 HMI LC into the mounting cut-out from the front.

*Figure 21
Installation*



*Figure 22
Installation*



Figure 23
Installation



2. Insert the fixing clamps into the housings of the device.

Figure 24
Installation




Figure 25
Installation



3. Tighten the fixing clamps with a 1.5 mm hex key.

*Figure 26
Installation*



Note:
adhere to the permissible torque
when tightening the threaded pin of
the mounting clamp: 0.2 Nm.

*Figure 27
Installation*



4. Repeat steps 2 and 3 for all mounting clamps.
5. Check the seal seat.

3.8 Connecting the unit

3.8.1 Information for the connection

- The C6 HMI / C6 HMI LC must be installed in accordance with the data contained in this instruction manual.
- This units are designed for the connection with a "Secondary Circuit Overvoltage Category II".

3.8.2 Power supply connection

The device may only be connected to a 24V power supply (max. permissible operating voltage range 18V to 36V) that meets the requirements of a safe extra low voltage (safe extra low voltage - SELV) according to IEC/EN/DIN EN/UL60950-1.

The power supply must meet the requirements of NEC Class2 or LPS in accordance with IEC/EN / DIN EN/UL60950-1.

Connect the unit with a cable cross-section of 0.75 - 1.5 mm² (AWG18 to AWG16 suitable for min. 75C°).


- Remove the poles connector plug from the system.
- Connect the positive wire to the positive terminal of the three pole connector.
- Connect the negative wire to the negative terminal of the three pole connector
- Connect the earth ground wire to the ground terminal of the three pole connector

(also refer to the label on the back of the system)



Attention: The system must be powered with a voltage of 24V (18V ÷ 36V).


*Figure 28
Power supply connection detail*





Note:
Value of tightening torque: 0.22 – 0.25 Nm.

Figure 29
Power supply connection detail



3.8.3 Switching on and testing the device

Connect the power supply cable to C6 HMI / C6 HMI LC. Switch On the power supply. The green led will light.

Figure 30
Power supply connection detail



The display will switch on accordingly, and after few seconds the Windows CE desktop will appear.

3.9 Connecting the configuration PC

You can connect the configuration PC to C6 HMI / C6 HMI LC in several ways:

- 1) By using a Ethernet cross cable connected by one end to the configuration PC and on the other end to one of two Ethernet ports of C6 HMI / C6 HMI LC.
- 2) By connecting C6 HMI / C6 HMI LC to a Ethernet switch on which the configuration PC and C6 HMI / C6 HMI LC are both connected.
- 3) By connecting C6 HMI / C6 HMI LC and the configuration PC to the office LAN.

Please note that C6 HMI / C6 HMI LC comes with DHCP service enabled. That means in case number 3 above it is sufficient to connect the C6 HMI in LAN; the LAN DHCP server automatically assigns an IP address to the C6 HMI / C6 HMI LC.

If no DHCP server is available, assign a static IP address to the C6 HMI / C6 HMI LC which is compatible with the IP address of the configuration computer.

Example: If the PC has the IP address 172.17.17.20, the C6 HMI / C6 HMI LC must be configured with the IP address 172.17.17.182. To configure the IP address on the table:

- Click on Start -> Settings -> "Network and Dial-up Connections"



*Figure 31
Connecting the configuration PC*

- According to the Ethernet port you want to configure, select the port to configure according to the following table:

*Table 23
Connecting the configuration PC*

LAN-Port of the C6 HMI / C6 HMI LC	LAN connection in the control panel
LAN1	General purpose
LAN2	COMBIVIS connect

- For instance if you need to configure LAN1 double click on FEC1, Click on "Specify an IP address" and write the IP address and default Gateway like in the figure below




Figure 32
Connecting the configuration PC

- Click on Ok to save the settings
- Click on Start -> Settings -> Control Panel



Figure 33
Connecting the configuration PC



- Then double click on “Registry Saver”



*Figure 34
Connecting the configuration PC*

Start | Network Connections | Control Panel | 11:56 AM |

- Click on the “Save” button and confirm clicking on “Ok”. This operation will save your setting in a permanent way.



*Figure 35
Connecting the configuration PC*



Start | Network Connections | Control Panel | Registry Saver Applet | 11:58 AM |

3.9.1 Procedure

After the connection between C6 HMI / C6 HMI LC and the configuration PC, to transfer the project into C6 HMI / C6 HMI LC you must:

- Start COMBIVIS studio HMI Developing tool.
- Load the project to transfer.
- Click on the transfer icon (see picture below).

*Figure 36
Connecting the configuration PC*




The following window will appear:

*Figure 37
Connecting the configuration PC*



Attention: please transfer the project into the MMC Memory or into the SD card. This allows you not to loose its content when C6 HMI / C6 HMI LC will be switched off.

To transfer the project into the MMC Memory, you must specify MMCMemory (like in the example of the picture above).



- Select TCP in the upper left list.
- Write the IP address of C6 HMI / C6 HMI LC
- Choose where to download the project into C6 HMI / C6 HMI LC specifying the "Upload Device Path".
- To transfer the project to C6 HMI / C6 HMI LC click on the button "Upload Project!".

There is another possibility to transfer the project to the panel. It is by using an USB key.


- Copy from the configuration PC to the USB Key the folder in which is stored the C6 HMI / C6 HMI LC project.
- Insert the USB Key into C6 HMI / C6 HMI LC.
- Copy the project folder from the USB Key to the MMC memory.

*Table 24
Procedure*

Note: the name of the memory card are according to the following table:

Memory	Name used by Windows Explorer	Note
NAND	NANDFlash	Used internal memory to store the operating system. It is a read only memory.
MMC	MMCMemory	Memory to store data and executables.
SD	SDMemory	Read and Write memory.
USB Key	Hard Disk	Removable Memory. Read and Write memory. USB key inserted into a USB port of C6 HMI / C6 HMI LC.

In the picture below an example of file Explorer on C6 HMI / C6 HMI LC.



*Figure 38
Connecting the configuration PC*

SECTION 4

Commissioning the device

4.1 Backup design

The C6 HMI / C6 HMI LC is equipped as standard with two memories: a NAND flash memory and an e-MMC memory card. Purpose of the NAND memory is to store the boot loader (is used during the start-up of the C6 HMI / C6 HMI LC), the operating system and all executable programs. Writing on the NAND memory can be switched on and off with a special program in order to protect the saved data on the NAND memory.

The e-MMC memory cards can be used to store other data such as process data or other executable programs. It is not possible to switch off the writing of MMCs. You can always read and write the eMMC memory. This memory is used to store data which are generated during the operation of the machine or plant and monitored by the C6 HMI / C6 HMI LC.

4.2 Internal memory

The NAND memory, as default is read only. In this manner it is protected against data loss; but the NAND memory can be made writeable.

To make the NAND memory writable, click in the Windows folder of the C6 HMI / C6 HMI LC on MakeNANDWritable (see picture below). By this way, you can store some exe files permanently safe. After the operation you can make the NAND memory "read only" as before.

In order to set the NAND memory to "read only", click in the C6 HMI / C6 HMI LC Windows folder on MakeNANDReadOnly (see picture below).





Figure 39
Commissioning the device

4.3 Slot for memory card (from 5.7")

C6 HMI / C6 HMI LC can optionally accommodate an SD/SDHC card slot V. 2.0 (push-push type).

*Figure 40
Slot for memory card*



Attention: potential data loss
Do not remove the memory card while data is being accessed.
Data on the memory card is lost if you attempt to remove it while C6 HMI / C6 HMI LC is accessing its data.

*Figure 41
Slot for memory card*




Attention: removing the system memory card while the project is running. If you remove memory card while a project is running, the project may stop.

*Figure 42
Slot for memory card*

4.4 Installation/removal of a memory card

- Insert the memory card into the slot as indicated in the figure. Pay attention to the beveled edge.



- Push the card all the way.



Figure 43
Slot for memory card



- Push the card previously inserted.

Figure 44
Slot for memory card



- Extract the memory card from the slot.

Figure 45
Slot for memory card



SECTION 5

Commissioning a project

5.1 COMBIVIS studio HMI project

5.1.1 Overview

Configuration phase

A project includes screen, alarms, variables used to represent the real plant of machine. The configuration phase is the creation of the project according to the user needs and interaction between the humans and the machine.

Transferring the project to C6 HMI / C6 HMI LC

You can transfer a project to C6 HMI / C6 HMI LC as follows:

- Transfer from the configuring PC by using an Ethernet connection
- Copy the Project by using a USB key

Process control phase

After the project is transferred, C6 HMI / C6 HMI LC is ready to communicate to one or more PLC and to visualize the screens according to the configured project.

ATTENTION: if you need to communicate with a device connected to the serial port you must configure the serial port. See chapter 5.1.3.

Commissioning and re-commissioning

When you switch on the first time C6 HMI / C6 HMI LC, there is no project inside. At first you need to transfer a project into C6 HMI / C6 HMI LC.

After you download a project, you can retransfer another project or another version of the same project without any special operation, also while the project is running on C6 HMI / C6 HMI LC.

5.1.2 Transfer

The C6 HMI / C6 HMI LC is always ready for accepting the download of a project, even when a project is running. In this way, if The C6 HMI / C6 HMI LC is connected by means of Ethernet to the configuration PC, you are able to download a new project or a new version of the same project even without stopping the project.


5.1.3 Configuration the serial port

If your project need to communicate with a device connected to the serial port, you need to configure the serial port according to the type of serial connection you use for your communication. The following types of communications are supported by the serial port of C6 HMI / C6 HMI LC:

- RS 232
- RS 422
- RS 485


C6 HMI / C6 HMI LC comes as default with the serial port set as RS 232. If you want to change the type of serial communication you must do the following:

Click on Start -> Settings -> Control Panel




*Figure 46
Configuring the serial port*

Double click on "Serial Port Configuration"



*Figure 47
Configuring the serial port*


Choose the type of serial communication



*Figure 48
Configuring the serial port*

And confirm by pressing the “Apply” button. A warning message will raise, advising to store that new configuration is active and saved a permanent way.

*Figure 49
Configuring the serial port*



This applet can be used just to check which serial communication mode is active; in this case it is enough to push the “red cross” on the high right side of the panel.

Please note that MPI mode cannot be selected: when this protocol will be used by HMI software all required settings will be applied automatically.

5.1.4 Connecting the serial port

A unique DB15 male connector hosts all serial protocols (please check par. 7.3.1 for pin-out details) so it is necessary to adapt this connection to plant needs; KEB can supply connector adapters as optional parts but user can adapt DB15 connector by himself.


5.1.5 Project administration

The C6 HMI / C6 HMI LC has high-performance tools to manage a running project. With the same mask that is used for the project transfer (see below), you can also:

1. stop the C6 HMI / C6 HMI LC project from the configuration PC
2. start the C6 HMI / C6 HMI LC project from the configuration PC
3. debug the project from the configuration PC
4. Transfer the project from C6 HMI / C6 HMI LC to the configuration PC

5.1.6 Stopping the running project

*Picture 50
Stop running project*



Please follow these steps to stop a running project:

5. Select TCP in the upper left list
6. Insert the IP address of the C6 HMI / C6 HMI LC
7. Click the button "Stop Device Project!"

You will see the project in C6 HMI / C6 HMI LC stopping (see below)


*Picture 51
Stop running project*



5/20/2016 12:08:31 PM You are running with a valid license
Start | Control Panel | COMBIVIStudio HMI - [Shutting down] | Output | 99396(63946) | 12:08 PM

5.1.7 Starting the project

Picture 52
Starting the project



To start a project in C6 HMI / C6 HMI LC by using the configuration PC you must:

8. Select TCP in the upper left list
9. Insert the IP address of the C6 HMI / C6 HMI LC
10. Click the button "Start Device Project"

Now you see how the C6 HMI / C6 HMI LC project is starting.


5.1.8 Debugging the project

You can debug the project in C6 HMI / C6 HMI LC by connecting with the configuration PC.

In order to be able to use the debugging functionality you must prepare your project as follows:

1. Select “Networking” in the project explorer window of COMBIVIS studio HMI
2. Enable the property “Debugger” in the Properties window of COMBIVIS studio HMI

*Picture 53
Debugging the project*



Transfer the project to the C6 HMI / C6 HMI LC and start running.


NOTE: Ensure that the project is running; otherwise you cannot debug it.

In order to debug the running project of the C6 HMI / C6 HMI LC from the configuration PC, follow these steps:

1. Select TCP in the upper left list
2. Insert the IP address of the C6 HMI / C6 HMI LC


Click the button “Attach To Process...”

Picture 54
Debugging the project



The following window will appear:

Picture 55
Debugging the project



Enter the IP address of the C6 HMI / C6 HMI LC and click "OK". A new window opens that asks for the user and the password

If the project is not protected, just click the "OK" button, otherwise enter the name and password of a project user who has the rights to modify the project.

Now you can see debugging is starting in COMBIVIS studio HMI on the configuration PC. Now you can:

- see the project screens and navigate between them. Please note you see a different screen than that of the C6 HMI / C6 HMI LC and the debugging does not affect normal operation of the C6 HMI / C6 HMI LC project.
- View and change the value of the variables
- Set a breakpoint and debug the Visual Basic scripts running in the project


5.1.9 Transfer the project from C6 HMI / C6 HMI LC to the configuration PC

This option allows you to transfer the project from C6 HMI / C6 HMI LC to the configuration PC in order to check or to change and hence transfer again into C6 HMI / C6 HMI LC.

Hint: It is always suggested to protect the project with a password in order to don't allow changes to the project by not authorized users.


Be sure that the project is not running on C6 HMI/C6 HMI LC, run COMBIVIS studio HMI on the configuration PC, click on the "File" menu and select "Open Device Project..."

*Picture 56
Debugging the project*



1. Select TCP in the upper left list
2. Write the IP address of the C6 HMI / C6 HMI LC
3. Write the path on which you want to store the project on your configuration PC
4. Click on the button "Get Project from Device!"

Picture 57
Debug the project



After the transfer of the project you will see the project explorer containing the project resources in COMBIVIS studio HMI and you can will able to check, test and change the resources of the project.

5.1.10 Backup and restore

The C6 HMI / C6 HMI LC has tools to backup and restore the contents of its internal memory in order to manage the project and the operating system of C6 HMI / C6 HMI LC. For more information please contact the support center of KEB.

5.1.11 Update the operating system

Please contact the Support Center of KEB.


5.2 COMBIVIS studio 6 project

This chapter is valid only for C6 HMI LC systems which are coming with CONTROL Runtime pre-installed directly from production.

5.2.1 C6 HMI LC – Implementation “CONTROL Runtime”

The CONTROL Runtime runs as a thread with “real time” priority.

The execution model is based on the “task” concept; the program execution requires the definition of tasks and the assignment of priority and execution cycle according to the following figure (see below in this manual about how to configure COMBIVIS studio 6 for use with C6 HMI LC system).



Each task is executed at the specified time interval and according to the assigned priority. Only when all the COMBIVIS studio 6 activities are over, the CPU time goes to the other processes, as they are assigned to an inferior priority.

Note: Each task cycle time must be properly assigned according to the general performances required by the Soft PLC itself, by the COMBIVIS studio HMI Runtime, by the COMBIVIS connect Runtime and by any other application or process running in the system. A too short task cycle time may introduce an undesired slowdown in the general reaction of the system. If this is the case, the task cycle time should be properly increased until you reach the proper balancing between performances and reactivity of the whole system.


5.2.2 Preparing the COMBIVIS studio 6 programming environment

The COMBIVIS studio 6 programming environment must be properly configured in order to support the code compiler for C6 HMI LC systems.


You need COMBIVIS studio 6 version 6.2.1.0_3.5.3.50 or above installed on the PC.

COMBIVIS studio 6 installation can be found in the COMBIVIS studio 6 user manual.

The C6 HMI LC can be shown in the device repository.




Create now a new project and insert the C6 HMI LC as new Device as shown in the following figure.



5.2.3 Transferring the COMBIVIS studio 6 application to the target system

To transfer a valid COMBIVIS studio 6 application to the Target system, follow these steps:

- Ensure the C6 HMI LC device is connected to the same sub network of the PC where you have running the COMBIVIS studio 6 programming tool (same network mask, e.g. "192.168.1.xx")
- Double click on the device icon from the COMBIVIS studio 6 project tree; the right part of the workspace will show the "Communication settings" tab contents
- Select the Gateway and click on the button "Scan network" button
- The box will be populated with the list of available CONTROL Runtime
- Click on the one you want to connect too and click then on the "Set active path" button
- Click On-line\Login to start the communication



5.2.4 I/O Fieldbus

The implementation "CONTROL Runtime" for KEB C6 HMI LC systems supports the following I/O fieldbuses:

- EtherCAT with NO DC support (distributed clock) on LAN1
- Modbus TCP on LAN1
- Modbus RTU


To insert the I/O master right click on the C6 HMI LC device icon on the project tree, select "Add Device" and select from the "Vendor" list box. The list will be populated with the available master devices. Select the one required by your application in between:

- EtherCAT Master
- Modbus COM (for Modbus based I/O both serial and TCP)

C6 HMI LC systems are featuring two Ethernet interfaces.

The interface that must be used for I/O fieldbus is the one denominated "LAN1".

Note: At the moment of transferring the PLC application to the target system, COMBIVIS studio 6 will ask to which interface the I/O must be attached. You must specify the MAC address of the "LAN1" interface as shown in the following figure.



Note: Current implementation if affected by a jitter of about +/- 2ms when working with I/O over Ethernet interface.

Note: The Ethernet interface assigned to an I/O Ethernet master (Ethercat or Modbus TCP) is exclusively dedicated to the I/O and must not be used for any other purpose (no programming, no COMBIVIS HMI protocol).

5.2.5 Support for retentive data

C6 HMI LC systems are equipped with a Micro UPS specifically designed to support the data memory retention.

In COMBIVIS studio 6 the retentive variables can retain their value throughout the usual program run period. They are declared as “Retain Variables” or even more stringent as “Persistent Variables”. For each case a separate memory area is used. Please check the COMBIVIS studio 6 manual for any additional detail about retentive data.

The use of the retentive areas does not require any specific configuration except for declaring the variable in the proper area according to the COMBIVIS studio 6 programming manual.

At the moment of a power failure (when the voltage is below the threshold for more than 50ms)

the UPS triggers an event and the system will switch off the display and the USB device connected in order to save energy, and will follow a four step sequence to save data:

1. The panel display and the USB ports are turned off
2. All running IEC tasks are terminated so the retentive areas are consistent
3. The system starts flushing the retentive memory areas to a file which is saved on disk
4. The CONTROL Runtime is terminated

The panel continues to run until the Micro UPS is able to provide power to C6 HMI LC.

Note: To start the backup procedure the super capacitors must be fully charged.

Note: The available retentive memory size is of 64KB for the RETAIN memory type and 64KB for the PERSISTENT memory type.

Note: If the power supply returns before the energy inside the Micro UPS is finished, and actually C6 HMI LC has not been switched off, the following operations are carried on:

- The display is switched on
- The USB ports are powered
- CONTROL Runtime behavior can be selected in between 3 possible models:
 - a. CONTROL Runtime does not start and no message is returned.
 - b. CONTROL Runtime does not start and returns a warning message.
 - c. CONTROL Runtime restarts normally (default option).

5.2.6 Use in combination with COMBIVIS HMI Runtime

COMBIVIS HMI Runtime can be of course configured to communicate with the CONTROL Runtime.


The C6 HMI LC includes the Gateway which is then used as communication interface.

The COMBIVIS studio HMI project must be configured to communicate with a generic CODESYS controller inserting in the “Real Time DB” resource the driver called “CODESYS” as shown in the following figure.




The protocol uses a socket to communicate with the CONTROL Runtime through the Gateway component.

The Station must be configured to connect to “localhost”. The Device name is the one shown by the programming system COMBIVIS studio 6 when connected on-line with the C6 HMI LC device from the “Communication settings” window as shown in the following figure.



The COMBIVIS studio HMI Station Properties will result as following.



The CONTROL Runtime running on a C6 HMI LC device can be reached also from a panel which has been configured to belong to the same sub network.

When having on the same sub network more than one C6 HMI LC system, you need to assign to them different name.

Note: In case the CONTROL Runtime is using Ethernet based I/O, the COMBIVIS studio HMI project must not be configured to use Ethernet protocols. The “LAN” interface is exclusively dedicated to the I/O, while the “WAN” interface is dedicated to the Internet connection for COMBIVIS connect and cannot be used as protocol port.

Note: The COMBIVIS studio HMI project can be configured to communicate with more than one controller; in these cases the system can act as a gateway and transfer data through the different channels. For further information about this feature consult the COMBIVIS studio HMI on-line manual searching for “Variable Commands” and then “Move Value”.

5.2.7 Use in combination with COMBIVIS connect

The C6 HMI LC systems are featuring COMBIVIS connect Runtime as preloaded and pre-configured.

The COMBIVIS connect VPN connection can be naturally used to connect from remote to the CONTROL PLC through the integrated Gateway. Once the VPN is activated, just follow the usual steps to get the on-line connection.

Please see the COMBIVIS connect Control Center on-line manual for further information about how to use the COMBIVIS connect software.

5.2.8 Limitations and Recommendations

In order to get the best balancing between functionalities and performances we strongly suggest to follow some guidelines when designing the applications for COMBIVIS studio 6 and COMBIVIS studio HMI.

- The PLC cycle time must be greater or equal than 10ms; the average jitter has been measured around +/- 2ms
- In general the CPU time reserved to CONTROL Runtime shall not be greater than 25%; this is calculated using the real time required by the PLC Runtime to complete the cycle and the time left free for all the other processes

Note: The maximum CPU time usable for the COMBIVIS studio 6 application is fixed from a system parameter; in case the PLC program gets more than 25% of the CPU time, the CONTROL Runtime will be stopped. The user shall then properly change the PLC task timing in order to respect the limitation.

- The maximum number of bytes exchanged between COMBIVIS studio HMI Runtime and CONTROL Runtime shall not be greater than 1024
- The sampling time specified for data acquisition shall not be less than 15sec
- The scripting shall be carefully used in order to leave enough time to the other tasks to run without impacting too much with the general reaction of the overall system
- If the project has been configured to use the Web Client, you should consider that when an external client is connect you may experience a slowdown of the page change performance of the COMBIVIS studio HMI Runtime
- The “S7-MPI COMx” communication protocol from COMBIVIS studio HMI is not supported.

SECTION 6

Maintenance


6.1 Calibration of the Touchscreen

C6 HMI / C6 HMI LC is designed to don't require touchscreen calibration, but in some cases, like update of the operating system, you must recalibrate the touch screen.

To calibrate the touch screen:


- Go in control panel.

*Picture 58
Calibration of the Touchscreen*




- Open the "Stylus" application.

*Picture 59
Calibration of the Touchscreen*



The following window will appear.

*Picture 60
Calibration of the Touchscreen*



- Click on the “Recalibrate” button and follow the instructions.

6.2 Maintaining & cleaning

C6 HMI / C6 HMI LC is designed for maintenance-free operation except for the replacing of the battery backup when necessary. It is recommended to clean the touchscreen with a damp cleaning cloth and a display cleaning solution.



Note: clean the front panel of the system with a soft damp cloth only.

 Attention: Do not use detergents, solvents, cleaners or objects that could scratch the surface.



Attention: switch off the power before any cleaning operation.

6.2.1 Procedure

Proceed as follows:

- a) Switch off the HMI device or lock the touch screen.
- b) Spray the cleaning solution onto a cleaning cloth.
- c) Do not spray directly onto the display.
- d) Clean the display from the screen edge inwards.

6.2.2 Backup battery replacement (CR2032 3V)

- Remove the two screws as indicated in figure.

*Figure 61
Backup battery replacement*



- Remove the two screws as indicated in figure.


*Figure 62
Backup battery replacement*



The following figures relate to the display models from 8.4" (inches).

- Remove the two screws as indicated in figure.

*Figure 63
Backup battery replacement*




- Remove the two screws as indicated in figure.

*Figure 64
Backup battery replacement*




*Figure 65
Backup battery replacement*




- Locate the battery position.

*Figure 66
Backup battery replacement*




- Remove the battery and replace it with one of the same model (CR2032 3V).

*Figure 67
Backup battery replacement*



*Figure 68
Backup battery replacement*



*Figure 69
Backup battery detail*



6.3 Technical support & repairs

KEB offers wide-ranging, complete after-sales technical support. The staff who deal with this handle questions on the entire range of products skilfully, quickly, and efficiently.

You can phone our staff in the service department, and they will give you complete, prompt advice on how to resolve your problems.

telephone:	+49 (0) 5263 401-0
Fax:	+49 (0) 5263 401-116
e-mail:	combicontrol@keb.de

6.4 Recycling and disposal

C6 HMI / C6 HMI LC can be recycled due to the use of materials with low environmental impact. Contact a certified disposal service company for environmentally sound recycling and disposal of your old devices.

SECTION 7

Technical specifications

7.1 Technical specifications

Table 25
System software characteristics

<i>System software characteristics</i>		
<i>Integrated system software</i>	Operating System	Microsoft Windows Embedded Compact 7 (C7P)
HMI	COMBIVIS studio HMI runtimes (Basic, ADVANCED versions)	
Remote control	COMBIVIS connect runtime	
Soft PLC	CONTROL Runtime	
<i>COMBIVIS studio HMI characteristics</i>	<i>BASIC</i>	<i>ADVANCED</i>
I/O Bytes (tags)	1.024	4.096
Synoptics	•	•
Graphic libraries	•	•
Power Templates	•	•
Alarms	512	2.048
Accelerators and menus	•	•
Touchscreen	•	•
History Log events	•	•
Dynamic language change	•	•
IL Logic (SoftLogic)	•	•
VBA Multithreading	•	•
ActiveX- OCX	•	•
CFR21 Part 11	•	•
Debugger Online/Remote	•	•
IP camera	•	•
Dynamic trends	•	•
Historical trends, data analysis	•	•
Recipes	•	•
OPC DA Client	•	•
Networking	•	•
Data Loggers	Max 2	•
Text Reports	•	•
Multi drives	Max 2	Max 4
SMS/E-mails	No	•
Web-Server	No	2 user
<i>COMBIVIS connect characteristics</i>	<i>PRO</i>	
Remote desktop	•	
File manager	•	
Task manager	•	
Chat	•	
Screenshot	•	
VPN with access to remote PC	•	
Ethernet subnet	•	
VPN up to remote PC	•	
Remoted serial (no MPI)	•	
API for customer application interface	•	
Persistence log on runtime operations	•	
Domain creation, user account and remote PC organisation structure	•	
Assistance requests reported by runtime	•	
Automatic connection	•	

*Table 26
MAIN FEATURES of CONTROL PLC
WinCE/ARM software*

MAIN FEATURES of CONTROL PLC WinCE/ARM software		
PLC Programming		COMBIVIS studio 6 Version 6.2.1.0_3.5.3.50
Supported protocols		EtherCAT Master, MODBUS TCP Master, MODBUS RTU Master
Retain variables	Size	64KB RETAIN + 64KB PERSISTENT
	management	Automatic backup of the retain variables on eMMC at every switch-off and/or power supply interruption
Project	Cycle time	≥ 10ms
	Jitter	± 2ms
	CPU occupation	max 25%
	Variable exchanged with PHMI	max suggested 1024
	Datalogging interval	Suggested > 15s
	CONTROL PRO Runtime	No
	S7 MPI COMx	No

*Table 27
System-hardware-characteristics*

System-hardware-characteristics		
	4.3"	4-wire – analog - resistive
	5.7"	4-wire – analog - resistive
	7.0"	4-wire – analog - resistive
	8.4"	5-wire – analog - resistive
	10.1"W	5-wire – analog - resistive
	10.4"	5-wire – analog - resistive
	12.1"	5-wire – analog - resistive
	12.1"W	5-wire – analog - resistive
	15.0"	5-wire – analog - resistive
	15.6"	5-wire – analog - resistive
Motherboard	Model:	All-in-one, KEB R131
	RTC	Hardware with battery-backup
	Buzzer	Yes
CPU	Processor	ARM Cortex A8 - Freescale i.MX535 - 1 GHz
	Memory bus	400MHz
Graphic	Controller	GPU with integrated LCD controller
System memory	Type / size / socket	1 GB / DDR3-800 / soldered (contact KEB for different memory options)
Serial interfaces	Type	1 x RS232/422/485 (DB15M) software selectable
	Optoisolation	No
Ethernet interfaces	Type	LAN1 100Mbps (RJ45) with Link/Activity leds LAN2 10/100Mbps (RJ45) with Link/Activity leds
USB interfaces	Type	2 x USB 2.0 (rear, TYPE-A, Host Port, switch off single-channel software)
Storage device	Internal / not removable	NAND-FLASH: 256 MB (Read Only) for operative systems, COMBIVIS studio HMI and COMBIVIS connect. eMMC: 4 GB - 8 bit v. 4.4 compatible (for data and application program) External access / removable SD/SDHC card slot V. 2.0 (push-push Type) (at 4.3" not available)
Battery	Type	Coin (CR2032 3V) removable
	Lifetime	3 years
Buttons, LEDs and keys	Reset button	System
	LEDs	Power / removable disk drive active

Table 28
Electrical characteristics

Electrical characteristics		
Power supply	Type	integrated on PC board, auto ranging
Input voltage	18÷36 VDC with 3-pin plug	
Protection	Anti-inversion polarity, overvoltage, soldered fuse on the PC board	
Micro UPS		500ms of back up time after 7 years of life at an average temperature of 45°C First load: 6 min Rearm time: 90 sec
Power consumption (max.) with USB ports loaded		12.0W@5,7" 13.0W@7,0" 13.5W@8,4" 15.5W @10,4" 19.5W @12,1" (SVGA) 21.5W @15,0" 23.0W @15,6"

These devices are designed to be connected with a "secondary circuit overvoltage category II".

Table 29
Mechanical characteristics

Mechanical characteristics		
Housings	Type	Panel mounting
Material	Steel, white zinced	
Front panel	Construction	Full aluminium-alloy
Protection	IP66	
Color	-	

Table 30
Environment characteristics

Environment characteristics		
Temperature	Operation	0° ÷ +50°C
	Storage	-20° ÷ +60°C
Humidity	Operation/storage	80% (non-condensing)

*Table 31
Displays*

Displays		
4.3"	LCD size	4.3"
	Resolution	480 x 272
	Colors	16M
	Backlight	Sidelight LED
5.7"	LCD size	5.7"
	Resolution	640 x 480 (VGA)
	Colors	256K
	Backlight	Sidelight LED
7.0"W	LCD size	7" wideband
	Resolution	800 x 480 (WVGA)
	Colors	16M
	Backlight	Sidelight LED
8.4"	LCD size	8.4"
	Resolution	800 x 600 (SVGA)
	Colors	16M
	Backlight	Sidelight LED
10.1"W	LCD size	10.1"
	Resolution	1280x800 (WXGA)
	Colors	16M
	Backlight	Sidelight LED
10.4"	LCD size	10.4"
	Resolution	800 x 600 (SVGA)
	Colors	16M
	Backlight	Sidelight LED
12.1"	LCD size	12.1"
	Resolution	800 x 600 (SVGA)
	Colors	16M
	Backlight	Sidelight LED
12.1"W	LCD size	12.1"
	Resolution	1280x800 (WXGA)
	Colors	16M
	Backlight	Sidelight LED
15.0"	LCD size	15.0"
	Resolution	1024 x 768 (SXGA)
	Colors	16M
	Backlight	Sidelight LED
15.6"W	LCD size	15.6"
	Resolution	1366 x 768 (XGA)
	Colors	16M
	Backlight	Sidelight LED

*Table 32
Guarantee and certifications*

Guarantee and certifications		
CE	Emission	In accordance with EN 55022 Information technology equipment - radio interferences - max. permissible values and measurement procedures
	Immunity	In accordance with EN 55024 Information technology equipment - noise immunity - max. permissible values and test procedures
	Safety	In accordance with EN 60950-1 – Information technology equipment - Safety - Part 1: General requirements
	Programmable controller 4WZ2 E356364	

7.1.1 4.3" Display characteristics

Table 33
4.3" Display characteristics

<i>4.3" Display characteristics</i>	
<i>Dimensions</i>	4.3" (4:3)
<i>Technology</i>	TFT active matrix
<i>Display area</i>	appr. 95.0 (W) x 54.0 (H) mm
<i>Resolution</i>	480 x 272 pixel
<i>Display color</i>	16 M colors
<i>Pixel Pitch</i>	0.198 (W) x 0.198 (H) mm
<i>Brightness</i>	400 cd/m ² (Note 1)
<i>Horizontal angle</i> (left + right)	130°
<i>Vertical angle</i> (up + down)	90°
<i>Contrast ratio</i>	250:1
<i>Response time (increasing)</i>	40 ms (Type)
<i>Backlight</i>	LED
<i>LED life (Note 2)"</i>	50.000h @ default (Note 3) and max. Tamb

7.1.2 5.7" Display characteristics

Table 34
5.7" Display characteristics

<i>5.7" Display characteristics</i>	
<i>Dimensions</i>	5.7" (4:3)
<i>Technology</i>	TFT active matrix
<i>Display area</i>	115.2 (W) x 86.4 (H) mm
<i>Resolution</i>	640 x 480 pixel
<i>Display color</i>	256 K colors
<i>Pixel Pitch</i>	0.18 (W) x 0.18 (H) mm
<i>Brightness</i>	500 cd/m ² (Note 1)
<i>Horizontal angle</i> (left + right)	70° + 70°
<i>Vertical angle</i> (up + down)	45° + 55°
<i>Contrast ratio</i>	250:1
<i>Response time (increasing)</i>	50 ms (Type)
<i>Backlight</i>	LED
<i>LED life (Note 2)"</i>	40.000h @ default (Note 3) and max. Tamb

7.1.3 7.0"W Display ,

Table 35
7.0"W Display characteristics

<i>7.0"W Display characteristics</i>	
<i>Dimensions</i>	7" wide (15:9)
<i>Technology</i>	TFT active matrix
<i>Resolution</i>	800 x 480 pixel
<i>Display color</i>	16M colors
<i>Pixel Pitch</i>	0.1905 (W) x 0.1905 (H) mm
<i>Brightness</i>	500 cd/m ² (Note 1)
<i>Horizontal angle</i> (left + right)	70° + 70°
<i>Vertical angle</i> (up + down)	70° + 60°
<i>Contrast ratio</i>	400:1 (Type)
<i>Response time (increasing)</i>	10 ms
<i>Backlight</i>	LED
<i>LED life (Note 2)"</i>	40.000h @ default (Note 3) and max. Tamb

7.1.4 8.4" Display characteristics

Table 36
8.4" Display characteristics

<i>8.4" Display characteristics</i>	
<i>Dimensions</i>	8.4" (4:3)
<i>Technology</i>	TFT active matrix
<i>Display area</i>	170.4 (W) x 127.8 (H) mm
<i>Resolution</i>	800 x 600 pixel
<i>Display color</i>	16M colors
<i>Pixel Pitch</i>	0.213 (W) x 0.213 (H) mm
<i>Brightness</i>	350 cd/m ² (Note 1)
<i>Horizontal angle</i> (left + right)	75° + 75°
<i>Vertical angle</i> (up + down)	60° + 70°
<i>Contrast ratio</i>	600:1 (Type)
<i>Response time (increasing)</i>	10 ms (Type)
<i>Backlight</i>	LED
<i>LED life (Note 2)"</i>	50.000h @ default (Note 3) and max. Tamb

7.1.5 10.1" W Display characteristics

*Table 37
10.1" W Display characteristics*

10.1" W Display characteristics	
Dimensions	10.1" W (16:10)
Technology	TFT active matrix
Display area	216.96 x 135.6
Resolution	1280 x 800 pixel
Display color	16M colors
Pixel Pitch	0.1695 (W) x 0.1695 (H) mm
Brightness	400 cd/m ²
Horizontal angle (left + right)	85° + 85°
Vertical angle (up + down)	85° + 85°
Contrast ratio	800:1
Response time (increasing)	25 ms
Backlight	LED
LED life (Note 2)"	100.000h

7.1.6 10.4" Display characteristics

*Table 38
10.4" Display characteristics*

10.4" Display characteristics	
Dimensions	10.4" (4:3)
Technology	TFT active matrix
Display area	211.2 (W) x 158.4 (H) mm
Resolution	800 x 600 pixel
Display color	16M colors
Pixel Pitch	0.264 (W) x 0.264 (H) mm
Brightness	400 cd/m ² (Note 1)
Horizontal angle (left + right)	80° + 80°
Vertical angle (up + down)	60° + 80°
Contrast ratio	700:1 (Type)
Response time (increasing)	20 ms (Type)
Backlight	LED
LED life (Note 2)"	50.000h @ default (Note 3) and max. Tamb

7.1.7 12.1" (SVGA) display characteristics

*Table 39
12.1" (SVGA) display characteristics*

12.1" Display characteristics	
Dimensions	12.1" (4:3)
Technology	TFT active matrix
Display area	246.0 (W) x 184.5 (H) mm
Resolution	800 x 600 pixel
Display color	16M colors
Pixel Pitch	0.3075 (W) x 0.3075 (H) mm
Brightness	500 cd/m ² (Note 1)
Horizontal angle (left + right)	80° + 80°
Vertical angle (up + down)	70° + 70°
Contrast ratio	800:1 (Type)
Response time (increasing)	4 ms (Type)
Backlight	LED
LED life (Note 2)"	100.000h @ default (Note 3) and max. Tamb

7.1.8 12.1" W display characteristics

Table 40
12.1" W Display characteristics

12.1" W Display characteristics	
Dimensions	12.1" (16:10)
Technology	TFT active matrix
Display area	261.12 x 163.2
Resolution	1280 x 800 pixel
Display color	16M colors
Pixel Pitch	0.204 (W) x 0.204 (H) mm
Brightness	400 cd/m ²
Horizontal angle (left + right)	88° + 88°
Vertical angle (up + down)	88° + 88°
Contrast ratio	1000:1
Response time (increasing)	25 ms
Backlight	LED
LED life (Note 2)"	50.000 h

7.1.9 15.0" Display characteristics

Table 41
15.0" Display characteristics

15.0" Display characteristics	
Dimensions	15.0" (4:3)
Technology	TFT active matrix
Display area	304.1 (W) x 228.1 (H) mm
Resolution	1024 x 768 pixel
Display color	16M colors
Pixel Pitch	0.297 (W) x 0.297 (H) mm
Brightness	450 cd/m ² (Note 1)
Horizontal angle (left + right)	80° + 80°
Vertical angle (up + down)	70° + 70°
Contrast ratio	700:1 (Type)
Response time (increasing)	2 ms (Type)
Backlight	LED
LED life (Note 2)"	100.000h @ default (Note 3) and max. Tamb

7.1.10 15.6" W Display characteristics

Table 42
15.6" W Display characteristics

15.6" W display characteristics	
Dimensions	15.6" (16:9)
Technology	TFT active matrix
Display area	344.2 (W) x 193.5 (H) mm
Resolution	1366 x 768 pixels
Display color	16.7M colors
Pixel Pitch	0.252 (W) x 0.252 (H) mm
Luminance	300 cd/m ² (Note 1)
Horizontal viewing angle (left + right)	85°+85°
Vertical viewing angle (up + down)	80°+80°
Contrast ratio	500:1 (Typ.)
Response time (Rise)	8 ms (Typ.)
Backlight	LED
LED life (Note 2)	50.000h @ default (Note 3) and max Tamb


- Note 1 At maximum (100%) brightness setting.
 Note 2 After the LED life time, the backlight luminance may be reduced up to the 50% of the initial value.
 Note 3 The default backlight value is set at 80% of the maximum brightness by the operating system.
 Note that the user can modify the backlight brightness, using the related operating system mask.
 At 25°C, the above-indicated LED life is also guaranteed at 100% backlight brightness; instead, at higher ambient temperature and 100% backlight brightness, LED life time will decrease.

7.2 Certificates and approvals

<i>Warranty & approvals</i>		
	Emission	Conforms to: EN 55022 Information technology equipment – Radio disturbance characteristics EN 61000-3-2 Limits for harmonic current emissions EN 61000-3-3 Limitation of voltage fluctuation flicker EMC Directive 2014/30/EU ex 2004/108/EC
	Immunity	Conforms to: EN 55024 Information technology equipment – Immunity characteristics EN 61000-6-2 Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments EMC Directive 2014/30/EU ex 2004/108/EC
	Safety	Conforms to: EN 60950-1 – Information technology equipment – Safety
	Conforms to: EN 50581:2012 - Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances RoHs Directive 2011/65/EU	
	Industrial Control Equipment, UL508 Process Control Equipment Industrial Products, CAN/CSA C22.2 No. 142-M1987	

7.3 Ports PINOUT

7.3.1 COM1 – DB15M Serial




PIN	Signal	Input/output
1	+5 VDC	OUT
2	Transmission data (RS-232)	OUT
3	Received data (RS-232)	IN
4	Transmit To Send	OUT
5	Clear Tu Send	IN
6	Data set ready	IN
7	Ground	—
8	Data Terminal Ready	OUT
9	Carrier Detect	IN
10	Transmission Data +/Receive Data + (RS-485/RS-422)	Input/output
11	Transmission Data -/Receive Data - (RS-485/RS-422)	I/O
12	Ring Indication (RS-232)	IN
13	Receive Data + (RS-422)	IN
14	Receive Data - (RS-422)	IN
15	N.C.	N.C.



Any polarization or termination resistor is connected to RS422/485 channel so, if required, it has to be provided by the user into the plant connector.

7.3.2 LAN1 – LAN2



PIN	Signal
1	TX+
2	TX-
3	RX+
4	Shield
5	Shield
6	RX-
7	Shield
8	Shield

7.3.3 USB1 / USB2



Table 43
USB1 – USB2

PIN	Signal
1	+5 Vcc
2	USB data -
3	USB data +
4	GND

7.4 Technical support & repairs

KEB offers wide-ranging, complete after-sales technical support. The staff who deal with this handle questions on the entire range of products skilfully, quickly, and efficiently.

You can phone our staff in the service department, and they will give you complete, prompt advice on how to resolve your problems.

Telephone: +49 (0) 5263 401-0
Fax: +49 (0) 5263 401-116
e-mail: combicontrol@keb.de

Figure overview

<i>Figure 1 C6 HMI / C6 HMI LC 5.7"</i>	12
<i>Figure 2 Full aluminium front panel detail</i>	13
<i>Figure 3 Full aluminium front panel detail</i>	14
<i>Figure 4 C6 HMI 4.3" rear view</i>	15
<i>Figure 5 C6 HMI / C6 HMI LC 5.7" rear view</i>	15
<i>Figure 6 C6 HMI / C6 HMI LC 7.0" rear view</i>	15
<i>Figure 7 C6 HMI / C6 HMI LC 8.4" rear view</i>	16
<i>Figure 8 C6 HMI 4.3" side view</i>	17
<i>Figure 9 C6 HMI 4.3" side view</i>	17
<i>Figure 10 C6 HMI / C6 HMI LC 5.7" side view</i>	18
<i>Figure 11 C6 HMI / C6 HMI LC 5.7" side view</i>	18
<i>Figure 12 C6 HMI 4.3" connectors</i>	19
<i>Figure 13 C6 HMI / C6 HMI LC connectors label detail</i>	19
<i>Figure 14 C6 HMI / C6 HMI LC 5.7" connectors</i>	20
<i>Figure 15 C6 HMI / C6 HMI LC connectors label detail</i>	20
<i>Figure 16 C6 HMI / C6 HMI LC label detail</i>	21
<i>Figure 17 Configuration and project creation</i>	22
<i>Figure 18 Process management</i>	22
<i>Figure 19 Mounting position</i>	27
<i>Figure 20 Installation distances</i>	28
<i>Figure 21 Installation</i>	32
<i>Figure 22 Installation</i>	32
<i>Figure 23 Installation</i>	33
<i>Figure 24 Installation</i>	33
<i>Figure 25 Installation</i>	33
<i>Figure 26 Installation</i>	34
<i>Figure 27 Installation</i>	34
<i>Figure 28 Power supply connection detail</i>	35
<i>Figure 29 Power supply connection detail</i>	36
<i>Figure 30 Power supply connection detail</i>	36
<i>Figure 31 Connecting the configuration PC</i>	37
<i>Figure 32 Connecting the configuration PC</i>	38
<i>Figure 33 Connecting the configuration PC</i>	38
<i>Figure 34 Connecting the configuration PC</i>	39
<i>Figure 35 Connecting the configuration PC</i>	39
<i>Figure 36 Connecting the configuration PC</i>	40
<i>Figure 37 Connecting the configuration PC</i>	40
<i>Figure 38 Connecting the configuration PC</i>	41
<i>Figure 39 Commissioning the device</i>	44
<i>Figure 40 Slot for memory card</i>	45
<i>Figure 41 Slot for memory card</i>	45
<i>Figure 42 Slot for memory card</i>	45
<i>Figure 43 Slot for memory card</i>	46
<i>Figure 44 Slot for memory card</i>	46
<i>Figure 45 Slot for memory card</i>	46
<i>Figure 46 Configuring the serial port</i>	50
<i>Figure 47 Configuring the serial port</i>	50
<i>Figure 48 Configuring the serial port</i>	50
<i>Figure 49 Configuring the serial port</i>	51
<i>Picture 50 Stop running project</i>	52
<i>Picture 51 Stop running project</i>	52
<i>Picture 52 Starting the project</i>	53
<i>Picture 53 Debugging the project</i>	54
<i>Picture 54 Debugging the project</i>	55
<i>Picture 55 Debugging the project</i>	55
<i>Picture 56 Debugging the project</i>	56
<i>Picture 57 Debug the project</i>	57

<i>Picture 58 Calibration of the Touchscreen</i>	68
<i>Picture 59 Calibration of the Touchscreen</i>	68
<i>Picture 60 Calibration of the Touchscreen</i>	69
<i>Figure 61 Backup battery replacement</i>	70
<i>Figure 62 Backup battery replacement</i>	70
<i>Figure 63 Backup battery replacement</i>	71
<i>Figure 64 Backup battery replacement</i>	71
<i>Figure 65 Backup battery replacement</i>	71
<i>Figure 66 Backup battery replacement</i>	72
<i>Figure 67 Backup battery replacement</i>	72
<i>Figure 68 Backup battery replacement</i>	73
<i>Figure 69 Backup battery detail</i>	73

Table overview

<i>Table 1 Package</i>	11
<i>Table 2 Touchscreen</i>	21
<i>Table 3 Software options</i>	23
<i>Table 4 Graphic interface</i>	23
<i>Table 5 Alarm log</i>	23
<i>Table 6 Recipes – Data loggers</i>	23
<i>Table 7 Trends</i>	23
<i>Table 8 Users & Passwords</i>	23
<i>Table 9 Dynamic multilanguage</i>	24
<i>Table 10 Drivers</i>	24
<i>Table 11 Event Object</i>	24
<i>Table 12 Scaling Object</i>	24
<i>Table 13 Scheduler Object</i>	24
<i>Table 14 Logics</i>	24
<i>Table 15 Networking</i>	24
<i>Table 16 Child Projects</i>	24
<i>Table 17 Software options</i>	24
<i>Table 18 Visual studio source safe 2005 integration</i>	24
<i>Table 19 Web Server</i>	24
<i>Table 20 Touch Screen Support</i>	24
<i>Table 21 Cross Reference</i>	24
<i>Table 22 Debugger</i>	24
<i>Table 23 Connecting the configuration PC</i>	37
<i>Table 24 Procedure</i>	41
<i>Table 25 System software characteristics</i>	75
<i>Table 26 MAIN FEATURES of CONTROL PLC WinCE/ARM software</i>	76
<i>Table 27 System-hardware-characteristics</i>	76
<i>Table 28 Electrical characteristics</i>	77
<i>Table 29 Mechanical characteristics</i>	77
<i>Table 30 Environment characteristics</i>	77
<i>Table 31 Displays</i>	78
<i>Table 32 Guarantee and certifications</i>	78
<i>Table 33 4.3" Display characteristics</i>	79
<i>Table 34 5.7" Display characteristics</i>	79
<i>Table 35 7.0"W Display characteristics</i>	79
<i>Table 36 8.4" Display characteristics</i>	79
<i>Table 37 10.1"W Display characteristics</i>	80
<i>Table 38 10.4" Display characteristics</i>	80
<i>Table 39 12.1" (SVGA) display characteristics</i>	80
<i>Table 40 12.1"W Display characteristics</i>	81
<i>Table 41 15.0" Display characteristics</i>	81
<i>Table 42 15.6"W Display characteristics</i>	81
<i>Table 43 USB1 – USB2</i>	83



KEB Automation KG
Südstraße 38 • D-32683 Barntrup
fon: +49 5263 401-116 • fax: +49 5263 401-116
net: www.keb.de • mail: info@keb.de

KEB Antriebstechnik Austria GmbH
Ritzstraße 8 • A-4614 Marchtrenk
fon: +43 7243 53586-0 • fax: +43 7243 53586-21
net: www.keb.at • mail: info@keb.at

KEB Antriebstechnik
Herenveld 2 • B-9500 Geraadsbergen
fon: +32 5443 7860 • fax: +32 5443 7898
mail: vb.belgien@keb.de

KEB Power Transmission Technology (Shanghai) Co.,Ltd.
No. 435 Qianpu Road, Chedun Town, Songjiang District,
CHN-Shanghai 201611, P.R. China
fon: +86 21 37746688 • fax: +86 21 37746600
net: www.keb.cn • mail: info@keb.cn

KEB Antriebstechnik Austria GmbH
Organizační složka
K. Weise 1675/5 • CZ-370 04 České Budějovice
fon: +420 387 699 111 • fax: +420 387 699 119
net: www.keb.cz • mail: info.keb@seznam.cz

KEB Antriebstechnik GmbH
Wildbacher Str. 5 • D-08289 Schneeberg
fon: +49 3772 67-0 • fax: +49 3772 67-281
mail: info@keb-drive.de

KEB España
C/ Mitjer, Nave 8 - Pol. Ind. LA MASIA
E-08798 Sant Cugat Sesgarrigues (Barcelona)
fon: +34 93 897 0268 • fax: +34 93 899 2035
mail: vb.espana@keb.de

Société Française KEB
Z.I. de la Croix St. Nicolas • 14, rue Gustave Eiffel
F-94510 LA QUEUE EN BRIE
fon: +33 1 49620101 • fax: +33 1 45767495
net: www.keb.fr • mail: info@keb.fr

KEB (UK) Ltd.
6 Chieftain Business Park, Morris Close
Park Farm, Wellingborough GB-Northants, NN8 6 XF
fon: +44 1933 402220 • fax: +44 1933 400724
net: www.keb-uk.co.uk • mail: info@keb-uk.co.uk

KEB Italia S.r.l.
Via Newton, 2 • I-20019 Settimo Milanese (Milano)
fon: +39 02 33535311 • fax: +39 02 33500790
net: www.keb.it • mail: kebitalia@keb.it

KEB Japan Ltd.
15-16, 2-Chome, Takanawa Minato-ku
J-Tokyo 108-0074
fon: +81 33 445-8515 • fax: +81 33 445-8215
mail: info@keb.jp

KEB Korea Seoul
Room 1709, 415 Missy 2000
725 Su Seo Dong, Gang Nam Gu
ROK-135-757 Seoul/South Korea
fon: +82 2 6253 6771 • fax: +82 2 6253 6770
mail: vb.korea@keb.de

KEB RUS Ltd.
Lesnaya Str. House 30, Dzerzhinsky (MO)
RUS-140091 Moscow region
fon: +7 495 550 8367 • fax: +7 495 632 0217
net: www.keb.ru • mail: info@keb.ru

KEB Sverige
Box 265 (Bergavägen 19)
S-43093 Hälsö
fon: +46 31 961520 • fax: +46 31 961124
mail: vb.schweden@keb.de

KEB America, Inc.
5100 Valley Industrial Blvd. South
USA-Shakopee, MN 55379
fon: +1 952 224-1400 • fax: +1 952 224-1499
net: www.kebamerica.com • mail: info@kebamerica.co

More and newest addresses at <http://www.keb.de>

© KEB		
Document	20125246	
Part/Version	GBR	00
Date	2016-10-07	